

ESSENTIAL PERFECT GROUT TREATMENT PRIMER

500ML SKU: SC4U_ERS_GTP500

DESCRIPTION

A specialist cleaning primer that ideally prepares grout areas for recolouring, it removes stubborn staining from wall & floor grout joints and is suitable for use around plastic & enamel baths & showers. This fast and effective priming formula is recommended prior to using Perfect Grout for best results.

Stonecare4u Essential Perfect Grout Treatment Primer is a fast effective cleaner & primer specially formulated to pre-treat and ready the grout joints for the application of Essential Perfect Grout Colour Sealers. Suitable for use on wall & floor grout joints around non porous tiled surfaces.

DIRECTIONS FOR USE

SHAKE WELL BEFORE USING.

1. Read label before using and follow personal protection guidance.
2. Spray the grout joint from approx 20-30cm away.
3. Leave to work for 2-3 mins, then agitate with a stiff brush or scouring pad and rinse with clean water.
4. Allow grout joints to completely dry before applying Essential Perfect Grout Colour Sealers.

Always test Essential Perfect Grout Treatment Primer in an inconspicuous area on-site prior to use.

Please Note: Avoid splashes on sensitive surfaces such as metal, wood or clothing.

COVERAGE

N/A

PRECAUTIONS

KEEP OUT OF THE REACH OF CHILDREN & PETS

H314: Causes severe skin burns and eye damage. H290: May be corrosive to metals. H302+312+332: Harmful if swallowed, in contact with skin or if inhaled. H317: May cause an allergic skin reaction. H318: Causes serious eye damage. H335: May cause respiratory irritation. P264: Wash hands thoroughly after handling. P280: Wear eye protection. P305+351+338: IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. P301+330+331: IF SWALLOWED: rinse mouth. Do NOT induce vomiting. P302+350: IF ON SKIN: Gently wash with plenty of soap and water. P304+341: IF INHALED: If breathing is difficult, remove victim to fresh air and keep at rest in a position comfortable for breathing. P333+313: If skin irritation or rash occurs: Get medical advice/attention. P337+313: If eye irritation persists: Get medical advice/attention.



Product SDS sheet available to download from our website.

Instructions on this label are a guide and should not be considered complete. In the event of failure, the manufacturer shall be obliged to replace such product proven defective. It is the user's responsibility to ascertain the suitability and safety of this product thus assuming all liability and risk thereof. For more information, refer to the Product Application Sheet available from www.stonecare4u.co.uk.

STORAGE INFORMATION

Close nozzle after each use. Store out of direct sunlight, keep in original container only. **Store away from temperature extremes and direct sunlight. Use within 12 months of purchase. Once open, use within 3 months.**



USAGE GUIDELINES

Dwell Time	Applications/Coats	Application Method	Dilution
2-3 mins	1 application	Brush/Pad/Sponge	Undiluted